


# MINI BEVELER AMB-0307, AMBL-0307 ASSEMBLY



# MINI BEVELER AMB-0307, AMBL-0307 PARTS LIST

The part numbers with ( ) are included in the Assy parts written above them.

## AMB-0307 PARTS LIST

No.	Part No.	Part Name	Q'ty	Price
1	TB01274	Plate A Assy	1 set	
2	(TP16975)	Label A (warning)	1	
3	(TQ01684)	Label B (beveling level)	1	
4	TQ00210	Plate B	1	
5	TQ00211	Hex. Socket Head Screw 5 x 8	4	
6	TP18065	Plate Guide	2	
7	TP02862	Hex. Socket Head Cap Screw 5 x 15	4	
8	TP02152	Plain Washer	4	
9	TA9A895	Head Sub Assy A	1 set	
10	TP08013	Hex. Socket Head Cap Screw 5 x 25	2	
11	TP18056	Concentric Snap Ring	1	
12	TA9A583	Stopper Assy	1 set	
13	TP04827	Hex. Socket Set Screw with Flat Point 6 x 10	3	
14	TP18055	Eccentric Ring	1	
16	TQ00142	Aux. Ring	1	
17	TQ01629	Indexable Insert Set Screw 4X7	1	
18	TQ01628	Indexable Insert with Hole 12.7	1	
19	TQ00139	Spacer 38.5 x 43.8 x 0.05 (for adjustment)	1	
	TQ00140	Spacer 38.5 x 43.8 x 0.1 (for adjustment)	1	
	TQ00141	Spacer 38.5 x 43.8 x 0.2 (for adjustment)	1	
	TQ00298	Spacer 38.5 x 43.8 x 0.3 (for adjustment)	1	
20	TQ01630	Holder	1	
21	TA98634	Bearing Set Screw Assy	1 set	
22	TQ00954	Spindle	1	
23	TP00502	Sunk Key 4 x 4 x 9.5	1	
24	TP01609	Ball Bearing 6202ZZ	1	
25	TP14036	Gear	1	
26	TQ00955	Needle Roller Bearing TA1010Z	1	
27	TP10100	Bearing Cover	1	
28	TP10826	Packing	1	
29	LP08450	Pan Head Screw 5 x 25	1	
30	TP14041	Exhaust Cover	1	
31	TP14040	Silencer Plate	2	

## AMBL-0307 PARTS LIST

No.	Part No.	Part Name	Q'ty	Price
32	TB01273	Grip Tube Assy	1 set	
33	(TP14343)	Name Plate	1	
34	TP06715	Countersunk Flat Head Screw 5 x 8	1	
35	TQ00144	Housing	1	
36	TP14030	Pinion	1	
37	TP10133	Ball Bearing 609ZZ	2	
38	TP14034	End Plate B	1	
39	TP10130	Sunk Key 3 x 3 x 10	1	
40	TP14033	Rotor	1	
41	TA9A294	Blade Assy (4 pcs.)	1 set	
42	TP14031	Cylinder	1	
43	TP04061	Spring Pin 3 x 6	1	
44	TP10137	End Plate A	1	
45	TP15131	Cap	1	
46	TA98314	Valve Holder Sub Assy A	1 set	
47	(TP13542)	Label Switch	1	
48	TP00547	Valve Pin 3 x 20	1	
49	TP13541	Spring 1.2 x 29.4 x 25	1	
50	TP13540	Valve Ring	1	
51	TA98988	Feed Valve Assy	1 set	
52	TP00520	Valve Spring	1	
53	TP11797	Connection	1	
54	TP00857	Bushing M16XPT1/4	1	

## ACCESSORIES

No.	Part No.	Part Name	Q'ty	Price
15	TA93017	Knob Assy	1 set	
	TP01939	Hex. Socket Screw Key 4	1	
	TQ01628	Indexable Insert with Hole 12.7	1	
	TP04696	Hex. Socket Screw Key 3	1	
	TP08584	Hex. Nut M8	2	
	TP17133	Hex. Socket Set Screw 8 x 25 Special	2	
	TP18071	Spanner T-15F	1	
	TP02236	Bushing PT1/4 x NPT1/4 (AMB-0307)	1	
	TQ02350	Bushing PT3/8 x NPT3/8 (AMBL-0307)	1	
	TQ01635	Instruction Manual	1	