## **EXPLODED DIAGRAM: JEX-24**

## **MARNING**


This diagram is for your reference only. Do not attempt to service or repair the Tool.

Do not take the Tool apart. Contact an authorized Nitto dealer for all service and repair of the Tool.

Improper service and repair can cause accidents and service injuries.

Never attempt to modify the Tool. Never attempt service or repair the Tool yourself.

Exploded diagram/parts list are subject to change at any time without notice. (As of Oct. 2014)



The part numbers with ( ) are included in the Ass'y parts written above them.

No.	Part No.	Description	Qty	Price
1	TQ13402	Cylinder	1	
2	TP11992	O-Ring KS-9	1	
3	TP02250	Front Washer	1	
4	TB08714	Housing Sub Ass'y	1set	
22	(TQ12611)	Label Warning CE Mark	1	
5	TP01478	Cylinder Lock Pin	1	
6	TP02242	Piston	1	
7	TP02249	Rear Washer	1	
8	TB08715	Rear Bolt Ass'y	1	
23	(TQ12687)	Label Warning	1	
9	TP00389	Valve Cap	1	
10	TP00388	Valve Packing	1	
11	TA90037	Throttle Valve Ass'y	1set	
12	TP01557	Throttle Lever	1	
13	TQ00563	Spring Pin 3×20	1	
14	_	Needle O.D.3×180mm	23	

			1 -	
No.	Part No.	Description	Qty	Price
15	TA93189	Needle Guide Ass'y	1set	
16	(TQ01484)	Small Hex. Nut M8	1	
17	(TP16284)	Hex. Socket Head Cap Screw 8×45	1	
18	TP02246	Lock Ring	1	
19	TP02245	Needle Supporter O.D.3	1	
20	TP02243	Throttle Anvil	1	
21	TQ02349	Bushing M16×Rc3/8	1	

## Accessories

No.	Part No.	Description	Qty	Price
	TP00170	Hex. Socket Screw Key 6	1	
	TQ02350	Bushing R3/8×NPT3/8	1	
	TQ03262	Hose Nipple R3/8×3/8	1	
	TQ12717	Instruction Manual	1	
	TQ12718	Declaration of Conformity	1	